2462 L

For truck, car and light truck wheels dynamic balancing in a single measurement cycle.

Voice synthesizer confirms each operation and suggests wheel balancing procedure.

Laser adjuster identifies precisely weight placement location..



2462 L wheel balancer configuration:

- car and delivery truck wheel balancing
- truck wheel balancing
- calibration - separate for car and truck wheels
- voice synthesizer
- hood
- ALU Function – only for car wheels
- monitor LCD
- laser adjuster
- lift

Technical Data


Rim diameter range:	10" - 30"
Rim width range:	2" - 20"
Maximum wheel weight	200 kg
Balancing accuracy truck wheel	10 g
Balancing accuracy car wheel	1 g
Measuring speed	130 - 150 obr/min
Power of the drive engine	150 W
Electric supply	230V / 50 Hz
Pneumatic power supply	8 - 10 bar
Dimensions	1100/1630/1580
Weight	250 kg

UNI-TROL Sp. z o.o.
ul. Estrady 56
01-932 Warszawa

tel. (22) 817 94 21 22, 817 94 34 35, 834 90 13 14
SPRZEDAŻ wew. 118 i 121, SERWIS wew. 131 i 134
www.unitrol.pl | office@unitrol.pl | serwis@unitrol.pl

Standard equipment:





UNI-TROL Sp. z o.o.
ul. Estrady 56
01-932 Warszawa

tel. (22) 817 94 21 22, 817 94 34 35, 834 90 13 14
SPRZEDAŻ wew. 118 i 121, SERWIS wew. 131 i 134
www.unitrol.pl | office@unitrol.pl | serwis@unitrol.pl

Available Colors



Basic Colors





Custom Colors

UNI-TROL Sp. z o.o.
ul. Estrady 56
01-932 Warszawa



tel. (22) 817 94 21 22, 817 94 34 35, 834 90 13 14
SPRZEDAŻ wew. 118 i 121, SERWIS wew. 131 i 134
www.unitrol.pl | office@unitrol.pl | serwis@unitrol.pl

Additional Equipment

Index	Description	Photo
150400049	Cone 95-132 mm Ø40	
06.04.017.40	Cone 110-125 mm Ø40	
04.04.008.40	Cone 125-145 mm Ø40	
06.04.009.40	Cone 145-165 mm Ø40	

UNI-TROL Sp. z o.o.
ul. Estrady 56
01-932 Warszawa

tel. (22) 817 94 21 22, 817 94 34 35, 834 90 13 14
SPRZEDAŻ wew. 118 i 121, SERWIS wew. 131 i 134
www.unitrol.pl | office@unitrol.pl | serwis@unitrol.pl

Index	Description	Photo
150400043	Cone 122-174 mm Ø40	
190400018	Distance spacer for shaft Ø40	
W-U-5AH	Motorcycle wheel adaptor	
T-CĘG-001	Wheel Balancing Weight Plier& Hammer Tool	

UNI-TROL Sp. z o.o.
ul. Estrady 56
01-932 Warszawa

tel. (22) 817 94 21 22, 817 94 34 35, 834 90 13 14
SPRZEDAŻ wew. 118 i 121, SERWIS wew. 131 i 134
www.unitrol.pl | office@unitrol.pl | serwis@unitrol.pl

Index	Description	Photo
WT-2065-1	Wheel Weight Scraper Tool	

UNI-TROL Sp. z o.o.
ul. Estrady 56
01-932 Warszawa

tel. (22) 817 94 21 22, 817 94 34 35, 834 90 13 14
SPRZEDAŻ wew. 118 i 121, SERWIS wew. 131 i 134
www.unitrol.pl | office@unitrol.pl | serwis@unitrol.pl